



Safety Notice

To All Who Install and Maintain 3M™ Parking Barrier Gates

People's lives and property depend on your safe installation and maintenance of this parking gate. Listed below are some important safety instructions and precautions that you should follow. Failure to follow all safety precautions and instructions can result in serious injury or property damage. Refer to the equipment operator's manual before beginning any service work.

- Turn off power before beginning any maintenance work or repairs to this equipment.
- Frequently inspect the parking gate to be sure it is operating properly.
- Replace broken gate arms with only 1 x 4 inch (25 x 102 mm) soft wood. Use of metal or plastic gate arms can cause severe injury or property damage.
- Affix a warning label to every replacement arm. Replacement gate arms and labels may be obtained from your VAR.
- Keep hands clear of mechanism drive components (main shaft, connecting rod, belts, reducer).
- Do not touch heater assembly. Unit stays hot for a period of time after power is shut off.
- Electrical shock is possible at:
 - L1 and L2 terminals (even with power off)
 - Limit switches
 - Components protected by connection box cover

**Retain This Notice
And Refer To It Often**

**Equipment Key
And Important
Safety Instructions
Enclosed**